MANUAL

MINI METAL RECYCLE MACHINE (MINI MRM)



1. <u>MINI MRM DIMENSIONS</u> : 1200 MM. ×1500 MM. ×800 MM.

SINTAL 新台通商

Head office:台北縣 231 新店市建國路 257 號 8F-11 8F.-11, No.257, Jianguo Rd., Xindian City, Taipei County 231, Taiwan TEL:+886-2-2218-7071 FAX:+886-2-2218-7072

http://www.sintai-corp.com


ASSEMBLY EQUIPMENTS

nttp://www.sintai-corp.

This panel position set on side of mini MRM body

1. CONTROL PANEL FOR OPERATION AND LAMP DISPLAY





Control Panel Details

A: Pilot lamp for motor overload

B: Push botton for forward impeller

C: Push botton for stop impeller

D: Push botton for reverse impeller

E: Heater temperature controller

F: Heater selector switch "On - Off"

G: Emergency stop

2. CAST IRON CRUCIBLE AND LOWER COVER



SINTAI 新台通商

Head office:台北縣 231 新店市建國路 257 號 8F-11 8F-11, No.257, Jianguo Rd, Xindian City, Taipel County 231, Taiwan TEL:+886-2-2218-7071 FAX:+886-2-2218-7072 http://www.sintai-corp.com



3. IMPELLER



4. HANDLE FOR CONTROL IMPELLER UP AND DOWN




❖ Handle Down → Impeller Up

❖ In Case of Drain Aluminium : Move Handle Little Down (Impeller Slightly Up)

❖ In Case of Drain Dross : Move Handle Maximum Down (Impeller Maximum Up)

5. HANDLE FOR CLOSE AND LOCK LOWER COVER



Handle "A": This Handle for closing lower cover after pouring dross out

Handle "B": This Handle for lock lower cover after closing its by Handle "A"

6. LIQUID ALUMINIUM & DROSS RECEIVED PUSHCART

6.1 Liquid Aluminium Received Pushcart



6.2 Dross Received Pushcart

